VIDE CAPTURE/Software Compression Card





Worldwide Technical Support and Product Information

www.vecow.com

Vecow Corporate Headquarters

4F No52 Aly3 Lane182 Section 2 WenHua Rd Panchiao Dist New Taipei City Taiwan Tel: 886 2 2258 5665

For further support information, refer to the Technical Support and Professional Services appendix. To comment on Vecow Co., Ltd. documentation, refer to the Vecow Co., Ltd. web site at www.vecow.com.

© 2009–2011 Vecow Co., Ltd. All rights reserved.

Record of Revision

Version	Date	Page	Description	Remark
V1.0.0	Dec 2010	All	Perliminary Release	
V1.0.1	Feb 2011		Packing List	
V1.0.2	Feb 2011		Motion Detection and Audio	
V1.0.3	Jul 2011		SDK Function	
V1.0.4	Sep 2011	P26 to P30	Multiple Instance function	
V1.0.5	Nov. 2011	P9 to P10	RCA and BNC Cable Pin Assignment	

Declaimer

This manual is intended to be used as a practical and informative guide only and is subject to change without prior notice. It does not represent commitment from Vecow Co., Ltd. Vecow shall not be liable for direct, indirect, special, incidental, or consequential damages arising out of the use of the product or documentation, nor for any infringements upon the rights of third parties, which may result from such use.

Declaration of Conformity

- FCC This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.
- **CE** The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.

Copyright and Trademarks

This document contains proprietary information protected by copyright. All rights are reserved. No part of this document may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer. Company/product names mentioned herein are used for identification

Packing List

No.	Photo	Description	Qty
1		VMX-200-4/-8 Capture Card	1
2		VMX-200-4: 16 pin header to D-sub 15 Cable x 1 or VMX-200-8: 16 pin header to D-sub 15 Cable x 2	
3		D-Sub 15 to BNC Cable	1
4		Driver and Software CD	1
5		User Manual	1

Order Information

Part Number	Description
VMX-200-4	4-CH, D1, Real-time, Mini-PCI Express, 120 fps, Video Capture Card, include cables
	and SDK
VMX-200-8	8-CH, D1, Real-time, Mini-PCI Express, 240 fps, Video Capture Card, include cables
	and SDK

Table of Contents

Declaimer	iv
Declaration of Conformity	iv
Copyright and Trademarks	iv
FCC	iv
CE	iv
Packing List	V
Order Information	V
General Introduction	1
1.1 Overview	1
1.2 Product Specification	2
1.2.1 Specification of Vecow VMX-200-4	2
1.2.2 Specification of Vecow VMX-200-8	3
1.5 System Requirements 1.4 Machanical Dimension	4
1.4 Mechanical Dimension	5
Hardware Installation	6
2.1 Install VMX-200	6
2.2 Connector Pin Assignments	8
2.2.1 J1 Connector Pin Assignments	8
2.2.2 J2 Connector Pin Assignments	8
2.3 KCA and BNC Cable PIN Assignment	9
2.3.2 DB15 to 4 Video-in and 4 Audio-in cable pin assignment	, 10
Driver Installation	11
3.1 Install VMX-200 driver software	11
Software Application	14
4.1 Microsoft .NET Frame work installation	14
4.2 Start the VMX-200 application	15
4.3 Using the VMX-200 Application	16
4.3.1 Main Application Window	16
4.3.2 Camera Setup function	18
4.3.4 Audio Downstream Selection	18
4.3.5 Demonstration	19
4.4 Motion Detection	20
4.4.1 Software Interface	20
4.4.2 Gha selection selop 4.4.3 Threshold Interface	20
SDK Function	23
5.1 WINDOWS	23
5.1.1 Driver Bulla Gulae 5.1.2 Graphedit demo on Window System	23
5.1.3 Multiple Instance Function	28
5.2 Linux System	33
5.2.1 Driver Building Guide	33

1

General Introduction

1.1 Overview

Thank you for your purchase of the VMX-200 video capture card.

The Vecow VMX-200 Multi-channel high quality video/audio card is especially designed for surveillance applications. Integrated with mini PCIe interface, VMX-200 series provides outstanding digital to video transferring rate, intensive integration with wide-ranging systems, and flexibility for Build-to-Order.

Containing eight high quality NTSC/PAL video decoders with 10-bit A/Ds and 5-line comb filtering, VMX-200 series produces high definition digital Video output.

Digital Video/Audio output supports the bridging of up to four channels of digital video and audio from PCIe, and can output these streams over pins in BT.656 or I2S-style interfaces, respectively.

In addition, low power consumption and low heat design of VMX-200 series can save more system power and use most PC system resources.

The complete SDK supports and mini PCIe form factor, the Vecow VMX-200 series can be easily integrated into various machine, such like as BOX Computer, Mounted PC, Panel PC, POS/ATM system or Embedded board.

1.2 Product Specification

1.2.1 Specification of Vecow VMX-200-4

General	
Bus Type /Form Factor	Mini PCI Express
Dimensions(L x H)	51mm x 30mm
I/O Connector	1 x 16 pin header to D-Sub 15 cable
	1 x D-Sub 15 to BNC cable
Environment Certifications	FCC, CE, RoHS Compliance
Storage Temperature	-40°C to 85°C
Operate Temperature	0°C to 60°C
Video	
Maximum Channel Number	4
Input Connector	4 input BNC to D-Sub 15
Resolution	D1 (NTSC: 720 x 480 / PAL: 720 x 576)
	CIF (NTSC: 360 x 240 / PAL: 360 x 288)
	4CIF (NTSC: 704 x 480 / PAL: 704 x 576)
	DCIF (NTSC: 528 x 320 / PAL: 528 x 384)
	QCIF (NTSC: 180 x 120 / PAL: 180 x 144)
Recording Rate	4CH with full D1 resolution
	120 fps on NTSC system, 100 fps on PAL system
Audio	
Maximum Channel Number	4 mono or 2 stereo
Audio Input Connector	4 input RCA to D-Sub 15
Software	
OS Support	WindowsXP/VISTA/Windows7 (32 Bits or 64 Bits)
	Standard Linux kernel 2.6.32 and all above
SDK	VC++ / .NET
Recommend System	
CPU	Intel Core2 Duo E4500 2.2GHz
Memory	1GB
Graphics Unit	DirectX 9.0c compatible display card
Storage Size	500GB

General	
Bus Type /Form Factor	Mini PCI Express
Dimensions(L x H)	51mm x 30mm
I/O Connector	2 x 16 pin header to D-Sub 15 cable
,	2 x D-Sub 15 to BNC cable
Environment Certifications	FCC, CE, RoHS Compliance
Storage Temperature	-40°C to 85°C
Operate Temperature	0°C to 60°C
Video	
Maximum Channel Number	8
Input Connector	2x 4 input BNC to D-Sub 15
Resolution	D1 (NTSC: 720 x 480 / PAL: 720 x 576)
	CIF (NTSC: 360 x 240 / PAL: 360 x 288)
	4CIF (NTSC: 704 x 480 / PAL: 704 x 576)
	DCIF (NTSC: 528 x 320 / PAL: 528 x 384)
	QCIF (NTSC: 180 x 120 / PAL: 180 x 144)
Recording Rate	8CH with full D1 resolution
	240 fps on NTSC system, 100 fps on PAL system
Audio	
Maximum Channel Number	8 mono or 2 stereo
Audio Input Connector	2x 4 input RCA to D-Sub 15
Software	
OS Support	WindowsXP/VISTA/Windows7 (32 Bits or 64 Bits)
	Standard Linux kernel 2.6.32 and all above
SDK	VC++ / .NET
Recommend System	
CPU	Intel Core2 GHz Quad Q8400 2.66GHz
Memory	1GB
Graphics Unit	DirectX 9.0c compatible display card
Storage Size	750GB

1.2.2 Specification of Vecow VMX-200-8

1.3 System Requirements

Your PC must have the following hardware and software installed to be able to use the VMX-200 series:

naraware nequiences						
Item	VMX-200-4	VMX-200-8				
CPU	Intel Core 2 Duo	Intel Core 2 Quad				
	E4500 2.2GHz	Q8400 2.66GHz				
Memory	DDR2, 1GB	DDR2, 1GB				
Graphics Unit	DirectX 9.0c Compa	tible Display Card				
Storage Size	500 GB 750 GB					
Slot/Socket	One Available mini PCI-e 1.1					

• Hardware Requiremets

• Software Requirement:

Microsoft[®] Windows 7 or VISTA operating system or above.

1.4 Mechanical Dimension

Figure 1.1 Top view



Figure 1.2 Front view





Hardware Installation

2.1 Install VMX-200

Power input, GbE ports, COM ports and optional isolated DIO are located on the rear panel. In this section, we'll illustrate connectors on the rear panel.

Step1.

Before you install VMX-200, please power off the system for safty.





Please make sure PCB is firmly blocked on the board.

Step4.

Power On your system and install driver.

Step5.



Connect 16 pin to D-sub 15 Cable for source input. Detailed pin defination please refer to 2.1 section.

2.2 Connector Pin Assignments

The serial console interface connector is a 16 pin header to D-sub 15 Cable connector. A null modem cable is required to connect a workstation. 2.2.1 and 2.2.2 show the pin assignments for the serial console interface connector

2.2.1 J1 Connector Pin Assignments



Pin No.	1	3	5	7	9	11	13	15
Function	V1	V2	V3	V4	A1	A2	A3	A4
Pin No.	2	4	6	8	10	12	14	16
Function	GND							

2.2.2 J2 Connector Pin Assignments



Pin No.	1	3	5	7	9	11	13	15
Function	V5	V6	V7	V8	A5	A6	A7	A8
Pin No.	2	4	6	8	10	12	14	16
Function	GND							

2.3 RCA and BNC Cable Pin Assignment

2.3.1 Main board to DB-15 pin assignment





2.3.2 DB15 to 4 Video-in and 4 Audio-in cable pin assignment



Driver Installation

3.1 Install VMX-200 driver software

The screenshots shown below are taken from Windows 7 and may vary slightly depending the Operating System

CAUTION!

Step1.

When you boot your computer after you have installed the VMX-200 PCIe software compression card, Windows will automatically detect the existing card and the following Device Manager Message dialog appears automatically. Please click the "Browse my computer for driver software (advanced)" option.



Step2.	
Inser path. <u>Drive</u> [x8 [x6	the Software and Driver CD, and click " Browse " to choose the fil The driver folder on the Software and Driver CD is : <u>CD\Windows</u> <u>r\x86.zip or x64.zip</u> 6.zip] for 32 bit version windows system, include XP/Vista/Win7. 4.zip] for 64 bit version windows system, include XP/Vista/Win7.
<u></u>	Update Driver Software - Multimedia Video Controller
E	Browse for driver software on your computer
S	Search for driver software in this location:
	E:\Conexant\SWD-202587-004\SWD-202587-004\Conexant\Atlas\fr 👻 Browse
	 Include subfolders Let me pick from a list of device drivers on my computer This list will show installed driver software compatible with the device, and all driver software in the same category as the device.
	Next Cancel

When the driver is located, ome windows system will show "Windows Security Message" to warring you windows can't varify the publisher of this driver software, please select "Install this driver software anyway" option.



CAUTION!

CAUTION!

Step3.

After the driver installation is completed, the windows will pop-up the message as follow:





Software Application

Notice before installing the software:

Make sure your system has installed .NET frame work 2.0 especially the WinXP user. If the program is already installed you can safely precede the VMX-200 software and skip 4.1 section.

4.1 Microsoft .NET Frame work installation

The Microsoft .NET Frame work will install on windows install folder. For example, on WinXP SP3, you can check "Windows\Microsoft.NET\Framework" folder.

Otherwise, you can get the .NET Frame work here: <u>http://www.microsoft.com/download/en/details.aspx?id=19</u>



4.2 Start the VMX-200 application

Insert the VMX-200 installation and driver disk into your optical drive. Go to My Computer and double-click the optical drive, the folder displayed which looks like that shown in the screen shot below.

There are 32bit and 64bit version of the VMX-200 application, before you start the execution file, please make sure you choose the file compatible with your system. Start the VMX-200 application by double-click the VMX-200 icon.



4.3 Using the VMX-200 Application

4.3.1 Main Application Window

When entering the VMX-200 Program, the main interface screen will open as shown below.



Function	Description
Image Display Area	Video input image will show in here
Status area	The text will be highlighted under "Low-Light Detected", "Day Light
	Detected, or no motion Detected status
Status of image fps	fps of the image input channel

No	Function	Description
	Main Function	
1	START	Show the Video streaming on Image display area
2	PAUSE	Pause current video streaming
3	STOP	Close present video streaming
	PROPERTIES	
4	Camera Setup	Show the Video streaming on Image display area
5	Color Control	Video quality adjustment
6	Display Mode	
	Single (1x1)	Show 1 video streaming on image display area
	Quad (2x2)	Show 4 video streamings on image display area
	Niner (3x3)	Show 9 video streamings on image display area
	Hex (4x4)	Show 16 video streamings on image display area
7	Video Formate	
	YUV422	Full Color 422 Video display formate option
	YUV411	Full Color 411 Video display formate option
	Y8	Black/White Video display formate option
8	Video Standard	
	NTSC	Video system option
	PAL	Video system option
9	Output size: Every cl	nannel image size is control by this setting
	720x576	
	720x240	
	720x288	
	352x288	
10	Audio Downstream	Enable audio
	Clear	When detection function becomes highlighted text, use this function to
		restart it
12	Setup	Config the Motion Detection function*
	Enable	Checked this option to enable "Motion Detection" function
	Grid Selection	Click this item to select motion detection area. Once the cell selection
		is done, you need to specify the threshold values as next step
	Threhold Settings	An 8-bit programmable value used to determine of this function
13	About	Show this software version information

4.3.2 Camera Setup function

Show the Video streaming on Image display area.

Camera 1 30 fp	Camera 2 30 fps	
Camera 3 30 fp	Camera 4 30 fps	
Camera 5 30 fp	Camera 6 30 fps	
Camera 7 30 fp	Camera 8 30 fps	
Camera 9 fr	🗧 🗖 Camera 10 🗍 fps	Audio Downstream Select
Camera 11	F Camera 12 fps	Channel A (Audio 1 and 2)
Camera 13	🗧 🗖 Camera 14 🚺 fps	C Channel B (Audio 3 and 4)
Camera 15	🗧 🗖 Camera 16 🚺 fps	C Channel C (Audio 5 and 6)
Enable ODD cameras	Enable EVEN cameras	C Channel D (Audio 7 and 8)

Function	Description
LLC (Line Lock Camera)	If your CAMERA source support this
	function, please checked it.
Camera 1 to 16 check	You can tick the camera source you
box	want to display.
The BOX of fps	You can type 1 - 30 to control video
	display frame speed.
Enable ODD cameras	Enable 1,3,5,7,9,11,13,15 cameras.
Enable EVEN cameras	Enable 2,4,6,8,10,12,14,16 cameras.

4.3.3 Color Control Function

You can adjust every single video quality by your own.



Press **'Default'** to restore the original color setting of one VDEC. After you changed the setting, please press **'Apply'** to save it.

4.3.4 Audio Downstream Selection

Audio Line	Audio Downstream Channel	Speaker
1	А	Left
2	А	Right
3	В	Left
4	В	Right
5	С	Left
6	С	Right
7	D	Left
8	D	Right

Every audio channel accept 2 audio line input, and every audio line is apply for one video line. Please see this table.

When you change the setting , must press 'Apply' to save it

4.3.5 Demonstration

exant Helios 2.0.28.		
About		
dain Functions		
START		
PAUSE		
GTOP		
STUP		
ROPERTIES		
Camera Setup		
Color Control		
	E Down	
upstream Setup		
Record Setup		
H264 Encoding		
10010	at the second seco	
H264 Decoding		
FPGA Download		
AGC/VGA Setup		
Display Mode		
Single (1X1) Outed (2X2)	HITACHI CALL CALL CALL CALL CALL CALL CALL CAL	
C Missas (2/2)		
C Hex (4X4)		
ideo Format		
Y422 💌	Camera 1 12 fps Camera 5 11 fps Camera 9 0 fps Camera 13 0 fps	
ideo Standard	Camera 2 2 fps Camera 6 15 fps Camera 10 0 fps Camera 14 0 fps	
NTSC	Camera 3 17 fps Camera 7 13 fps Camera 11 0 fps Camera 15 0 fps	
C PAL	Camera 4 21 fps Camera 8 26 fps Camera 12 0 fps Camera 16 0 fps	
utput Size	- Motion Detection Status	_
720x480 💌	Low field Datasted Day Light Datasted No Mation Datasted	
	Light Developer Day Light Detector No motion Detector Light	

- 1. Press "CAMERA Setup" to select CAMERA source that you connect.
- 2. Select Video Standard: If you do not know your video system standar, please connect your video device vendor.
- 3. Select Video format & output size : If you are first running, please use the default setting.
- 4. Press "START" to download video streaming.

4.4 Motion Detection

4.4.1 Software Interface

On the Main screen of VMX-200 software, press "Setup" and you will see 3 sub items:

Enable	Checked this option to enable "Motion
	Detection" function.
Grid Selection	Click this item to select motion detection
	area. Once the cell selection is done,
	you need to specify the threshold values
	as next step.
ThresholdSettings	An 8-bit programmable value used to
	determine of this function.

4.4.2 Grid Selection Setup

tion Dete	ection Ar	ea Selec	tion										l		×	When open thi
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	option , the "Motio
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	Detection Are
33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	Selection " will show
49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	empty grid table
65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	170
81	82	83	84	85	86	87	88	89	90	<mark>9</mark> 1	92	93	94	95	96	
97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	
113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128	
129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	
145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160	
161	162	163	164	165	166	167	168	169	170	171	172	173	174	175	176	
177	178	179	180	181	182	183	184	185	186	187	188	189	190	191	192	



don Dece	Eccioii /		ceton						_							wulliple aleas a
Ĩ.	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	acceptable.
17	18			21	22	23	24	25	26	27		29	30	31	32	
33	34			37	38	39	40	41				45	46	47	48	
49	50			53	54	55	56	57	58	59		61	62	63	64	
65	66			69	70	71	72	73	74	75	76	77	78	79	80	
81	62				86	87	88	89	90	91	92	93	94	95	96	
97	98		100	101	102	103	104	105	106	107	108	109	110	111	112	
113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128	
129	130	131	132	133	134	135	196	137	158	139	140	141	1 42	143	144	
145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160	
161	162	163	164	165	166	167	168	169	170	171	172	173	174	175	176	
177	178	179	180	181	182	183	184	185	196	187	188	189	190	191	192	

4.4.3 Threshold Interface

1	Chemical Che	
(N	Aotion	
	Motion sensitivity threshold[255:0]:	3
	Motion number of blocks detected threshold[255:0]:	3
CN	No Motion	
	Still frame sensitivity threshold[285:0]:	2
	Still frame number of blocks detected threshold[255:0]:	186
	Still frame threshold[255:0]:	3
4	Black / Low Light Black pixel count threshold: Black pixel detection threshold[255:0]:	72000
V	White / Day Light	
	White pixel count threshold:	72000
	White pixel detection threshold[255:0]:	144
p Frame	Count	
	lumber of frames to skip[255:0](0 value processes every frame):	0

	1
Motion	The motion detection threshold is an 8-bit programmable value used to determine the presence of motion. This value represents a minimum delta between scaled block average luma values to indicate motion within a block. The motion number of blocks detected threshold is an 8-bit programmable register field that controls how many blocks must detect motion before the frame comparison indicates motion detected to the host and external interrupts.
No Motion	The still image threshold is an 8-bit programmable value used to determine a non-changing image. This value represents a maximum delta between scaled block average luma values to indicate a constant image within a block. The still number of blocks detected threshold register field indicates how many of the 192 grid regions detected a still image. The still frame threshold register field controls how many blocks per frame must detect a still image to cause the still image frame counter to increment. The still frame threshold field controls how many consecutive still frames are required before the interrupt is asserted.
Black/Low Light & White / Day Light	Black and white detection is performed on each field/frame that is used for motion detection. In order to detect the black and white, the following thresholds and limits are used:
	i. For every pixel of the field indicated by the top_bot_field_sel register field of the MDET_{x}_CTRL register, if the luma value is less than the black threshold, the black detection counter will be incremented.
	ii. If the luma value is greater than the white threshold, the white detection counter will be incremented.
	iii. If, at the end of the field, the black detection counter is greater than the black field limit value, a black detection will be signaled for that channel.
	iiii. If, at the end of the field, the white detection counter is greater than the white field limit value, a white detection will be signaled for that channel. The black and white detection counters will be reset before the beginning of the next field for detection.



SDK Function

5.1 Windows

5.1.1 Driver Build Guide

Before starting to build VMX-200 driver please ensure that you have installed the following development environment:

1. Visual Studio 2005 or later

2. Microsoft WDK 6000. More information on the following link http://www.microsoft.com/whdc/resources/downloads.mspx

3. Microsoft Windows Vista Software Development Kit. While installing the SDK give simple pathname (for e.g. SDK3.0) more information on the following link http://www.microsoft.com/downloads/en/ details.aspx?familyid=4377F86D-C913-4B5C-B87E F72E5B4E065&displaylang=en

After the installation on the VMX-200 SDK main directory create a batch file with the following contents. Let's assume the batch file name is 'setpath.bat'.

SET SDKROOT = (Full Directory path containing Windows Vista SDK e.g. C:\SDK3.0) **SET WDKROOT = (**Full Directory path containing WDK e.g. C:\WINDDK\6000)

Please run this batch file before compiling some of the modules s stated below.

 Modules in the CX25820/1 driver sources
 Capture and HeliosApp are the modules that comprise the full CX25820/1 software driver and application system. Please follow the steps to install: Before compiling Application software you need to the DirectShow base class. First, add DirectShow base class path to Visual Studio 2005 project. Secondly, add include path as the shot below:



Once the path for includes and libraries are set properly, you can start to compile the application to get the executable software.

• Compiler the cx25858 driver source

Open "Capture" module on source project.

- 1. Invoke your build environment as your target O.S
- 2. Change directory to SDK\Capture.
- 3. At the command prompt run the setpath.bat
- 4. Run the build utility with following options, build -c
- Build VMX-200 software

Open "HeliosApp" module on source project.

CAUTION

CAUTION!

5.1.2 Graphedit demo on Window System

The Microsoft DirectX SDK provides a very useful debugging utility called GraphEdit, which can be used to create Media device model. The demo of download video streaming with GraphEdit step:





 Audio Compressors Audio Renderers BDA CP/CA Filters BDA Receiver Component BDA Rendering Filters BDA Source Filters Device Control Filters DMO Audio Effects DMO Audio Effects DMO Audio Effects EncAPI Encoders External Renderers Midi Renderers Video Capture Sources Video Capture Sources Video Compressors WDM Stream Decompression Devices 	Goto the "DirectShow filter" class and get next filter.
---	---



Connect all device as below	
C 0: Video Composte In Out Anabo Video In Conexant CX25658 Video Capture Anabo Audo In Audo Out Anabo Audo In Anabo Audo In	



Step9.



Crossbar	perties	The properties o Crossbar device
- Input	Output	
U: Video Composite In Current Input: 0: Video Composite In Related Pin: 0: Video Composite In Current Input: 0: Video Composite In Current Input: 0: Video Composite In	C: Video Decoder Out	
OK Close	Apply Help	
exant CX25858 Video Capture Propert	ties Setup Frame Count Color Control	The properties o Capture device
Camera 1 Camera Camera 3 Camera Camera 3 Camera Camera 5 Camera Camera 7 Camera Camera 9 Camera Camera 11 Camera Camera 13 Camera Camera 13 Camera Camera 15 Camera Camera 15 Camera Rotate Display Sequence	2 VDEC_A 0 field(s) 4 VDEC_B 0 field(s) 6 VDEC_C 0 field(s) 8 VDEC_D 0 field(s) 10 VDEC_F 0 field(s) 12 VDEC_F 0 field(s) 14 VDEC_G 0 field(s) 16 VDEC_H 0 field(s) I Master duration for all decoders Help	
nexant Video Converter P Display	roperties	The properties o Video Converter
Display Mode © Single (1×1) © Quad (2×2)	C Niner (3×3) C Hex (4×4)	

Step10. Setup the properties of filter

5.1.3 Multiple Instance Function

On legacy capture card, one Video channel is only assign to one PCI video device. Although VMX-200 has multiple video channels, on Windows Device Manager you can only see one PCI device. In order to separate video streams from one video device, we are promote the "Multiple Instance" function. Please follow the step to enable "Multiple Instance" function on your system.

Step1.

We strongly suggest uninstalling current VMX-200 driver from Windows, but if new installed, please skipping this step.

a la		
ile Action View	Help	
e 🚔 cox-PC		
> 📲 Computer		
Disk drives		
Display adapt	ters Midrives	
D Ca IDE ATA/ATA	API controllers	
p - Keyboards		
D .Mice and oth	her pointing devices	
Monitors		
Ports (COM)	8 LPT)	
Processors		
. Sound, video	and game controllers	
- aj Intel(R) D	isplay Audio	
Realtek H	ligh Definition Audio	
⇒ di System di ⇒ di Universal	Update Driver Software	
	Disable	
	Uninstall	and the second
	Scan for hardware change	es
	Properties	
ninstalls the driver for t	he selected device.	
ninstalls the driver for t	he selected device.	
ninstalls the driver for t	he selected device.	Confirm Device Uninstall
ninstalls the driver for t	he selected device.	Confirm Device Uninstall
ninstalls the driver for t	he selected device.	Confirm Device Uninstall VMX-200 PCIe software compression card
ninstalls the driver for t	he selected device.	Confirm Device Uninstall VMX-200 PCle software compression card
ninstalls the driver for t	he selected device.	Confirm Device Uninstall VMX-200 PCle software compression card Warning: You are about to uninstall this device from your system.
ninstalls the driver for t	he selected device.	Confirm Device Uninstall VMX-200 PCle software compression card Warning: You are about to uninstall this device from your system.
ninstalls the driver for t	he selected device.	Confirm Device Uninstall VMX-200 PCle software compression card Warning: You are about to uninstall this device from your system.
installs the driver for t	this box,	Confirm Device Uninstall VMX-200 PCle software compression card Warning: You are about to uninstall this device from your system. Delete the driver software for this device.
lease tick	this box,	Confirm Device Uninstall VMX-200 PCle software compression card Warning: You are about to uninstall this device from your system. Delete the driver software for this device.
lease tick nd clear a	this box,	Confirm Device Uninstall VMX-200 PCle software compression card Warning: You are about to uninstall this device from your system. Delete the driver software for this device.
lease tick nd clear a les.	this box, all driver	Confirm Device Uninstall VMX-200 PCle software compression card Warning: You are about to uninstall this device from your system. Delete the driver software for this device. OK Cancel
installs the driver for t lease tick nd clear a les.	this box, all driver	Confirm Device Uninstall WIX-200 PCle software compression card Warning: You are about to uninstall this device from your system. Delete the driver software for this device. OK Cancel
installs the driver for t lease tick nd clear a les.	this box, all driver	Confirm Device Uninstall Image: Second Sec
installs the driver for t lease tick nd clear a les.	this box, all driver	Confirm Device Uninstall Image: Second Sec
lease tick nd clear a les.	this box, all driver	Confirm Device Uninstall Image: Second Sec
lease tick nd clear a les.	this box, all driver	Confirm Device Uninstall Image: Second Sec

Step2.

Modify driver for multiple instance function. Please find the "CxAtlas.inf" and open it with Notpad. Goto the 118 line, you will see the text shows as below:

'HKR,"DriverData","EnableMultiInstances",0x00010001, 0x00, 0x00, 0x00, 0x00'

Please change 2nd value "0x00" to "0x01", the text as below: **'HKR,"DriverData","EnableMultiInstances",0x00010001, 0x01, 0x00, 0x00, 0x00'**

Please save your change and exit the Notepad.

Step3.

Re-install the VMX-200 driver with modified driver, please refer to chapter 3 Driver Installation.

Step4.





When enable multiple instance, you can create four CX25858 capture device. Please refer as upon figure.

Step5.

Play the Graph, there are four separate vidoe windows shows as follow graphics:



5.2 Linux System

5.2.1 Driver Building Guide

Before you start, please ensure you have root ID and password.



Please find as these two file that is on Linux SDK package v4l2_source_2.6.33.tar.bz2 cx25858_src_2.0.108.tar.gz

- Install v4l2 module
 - Type "tar -jxvf v4l2_source_2.6.33.tar.bz2" You will see a folder "v4l-dvb-abd3aac6644e". Please into this folder for next step.
 - 2. Type "make"
 - 3. Type "make install"
 - 4. Type "make clean"
 - 5. Type "make distclean"
- Upgrade driver source file to v4l2 module
 - 1. Copy "cx25858_src_2.0.108.tar.gz" to "v4l-dvbabd3aac6644e" folder.
 - Type "tar -zxvf cx25858_src_2.0.108.tar.gz". The cx25858 source file will copy to v4l2 driver folder. If prompt overwrite the file , please select 'yes'.
 - 3. Type "make menuconfig" (PS*1) Setup the configuration file



- 4. Type "make" (PS*2)
- 5. Type "make install"

- Install driver module
 - 1. Change to ""v4l-dvb-abd3aac6644e/v4l" folder.
 - 2. Type "modprobe cx25858"
 - 3. Type "modprobe cx25858-alsa". This is cx25858 audio module , that use ALSA function. (ALSA: Advanced Linux Sound Architecture)
- Check driver
 - 1. Type "Ismod" to check cx25858 driver.
 - 2. Type "dmesg" to see cx25858 driver status.
- Display the video stream
 - 1. Change to ""v4l-dvb-abd3aac6644e/linux/scrips" folder
 - 2. Use script command "mplay_video #" . (# is 0~7 , for video 1 to video 8)

For example : Display Video 1 , type "maply_video 0" Display Video 5 , type "maply_video 4"

Please refer the display image as below:

